

# Dune Scoop Protector Installation

Included with this kit:

- Mylar squares
- Metal protector
- #6 wood screws

You will need:

- Phillips #2 screwdriver
- ¼" nut driver

Step 1:

Apply mylar squares around the back, rear left, and rear right of the scoop on the top of the playfield. Be sure to fold the squares down into the hole on each side.



## Step 2:

Install the metal protector.

- Ensure the machine is powered off
- Remove the lockdown bar and playfield glass
- Install your plastic art blade protectors
- Lift the playfield into the service position (no need to remove the balls)
- Remove the screws from the plastic subway using the ¼" nut driver
  - Note: You do not need to unplug or fully remove the subway
- Line up the metal protector so it is sitting snugly against the playfield opening
- Ensure the mylar is sitting between the playfield and the metal protector
- Install the metal protector
  - First, screw down the right side (below the subway) using two new #6 wood screws
  - Next, use the existing subway screw to secure the left side
  - Finish re-installing the remaining subway screws

